

---

Meridian Administration Tools

# Traffic Analysis

## User guide

---

Document Number: P0859423

Document Release: Standard 4.60

Date: March 1997

---

© 1994, 1997

All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

---

## Revision history

---

**June 1994**

Standard, release 1.0.

**December 1994**

Standard, release 2.0.

**August 1995**

Standard, release 3.0.

**November 1995**

Standard, pre-release 4.0a for testing.

**February 1996**

Standard, pre-release 4.00 for field trials.

**May 1996**

Standard, release 4.00.

**March 1997**

Standard, release 4.60.

---

# Contents

---

|                                                        |           |
|--------------------------------------------------------|-----------|
| <b>Introduction</b>                                    | <b>1</b>  |
| Overview                                               | 1         |
| MAT users                                              | 2         |
| Conventions used in this manual                        | 3         |
| Traffic Analysis System Sizing Guidelines              | 4         |
| Traffic Database Capacity                              | 4         |
| Communications Throughput                              | 5         |
| System Resources                                       | 7         |
| <b>Getting Started</b>                                 | <b>9</b>  |
| Overview                                               | 9         |
| Traffic Analysis example                               | 10        |
| Connect to a Meridian 1                                | 10        |
| Collect traffic data from the Meridian 1               | 11        |
| Print a traffic report for incoming and outgoing calls | 12        |
| <b>User Interface</b>                                  | <b>15</b> |
| Traffic Analysis window                                | 15        |
| File menu                                              | 16        |
| Reports and Graphs menus                               | 17        |
| Printing reports and graphs                            | 17        |
| Reports menu                                           | 23        |
| Graphs menu                                            | 25        |
| “What-if” menu                                         | 26        |

|                                                          |           |
|----------------------------------------------------------|-----------|
| Processor load scenario . . . . .                        | 27        |
| Trunk scenario . . . . .                                 | 29        |
| Attendant console scenario . . . . .                     | 32        |
| Maintenance menu . . . . .                               | 34        |
| Traffic Database . . . . .                               | 34        |
| Traffic Data Collection . . . . .                        | 35        |
| Profile Editor . . . . .                                 | 36        |
| Filter Editor . . . . .                                  | 38        |
| Text File Editor . . . . .                               | 39        |
| Help menu . . . . .                                      | 40        |
| <b>Database Maintenance . . . . .</b>                    | <b>41</b> |
| Database Maintenance window . . . . .                    | 42        |
| Traffic database file names . . . . .                    | 42        |
| Traffic database operations . . . . .                    | 42        |
| Options menu . . . . .                                   | 46        |
| Log events . . . . .                                     | 46        |
| Leaving Database Maintenance . . . . .                   | 46        |
| <b>Report Generator . . . . .</b>                        | <b>47</b> |
| Reports . . . . .                                        | 48        |
| System reports . . . . .                                 | 49        |
| Customer reports . . . . .                               | 56        |
| Customer network traffic reports . . . . .               | 64        |
| System threshold reports . . . . .                       | 67        |
| Customer threshold reports . . . . .                     | 69        |
| Customer Summary Reports . . . . .                       | 71        |
| Graphs . . . . .                                         | 73        |
| System graphs . . . . .                                  | 74        |
| Customer graphs . . . . .                                | 75        |
| Messaging and auxiliary processor links graphs . . . . . | 75        |
| Customer network graphs . . . . .                        | 75        |
| System threshold graphs . . . . .                        | 75        |
| Customer threshold graphs . . . . .                      | 76        |
| Graph types . . . . .                                    | 76        |